

# TILING BATHROOM WALLS




## 01 PREPARE

Ensure the wall surface is clean, dry, and free from dust, grease, or loose material. Repair any damaged areas and allow to dry completely. Measure the wall and plan your tile layout carefully, using a level and chalk lines to mark reference points.



## 02 PRIME

Apply **Dunlop Multi Purpose Primer** to the wall surface using a brush or roller. This will improve adhesion and seal porous surfaces. Allow the primer to dry fully before proceeding. This step is crucial for ensuring a strong bond between the wall and the tile adhesive.



## 03 MIX

Mix **Dunlop CF-03** or **CF-24 Tile Adhesive** according to the instructions on the packaging, using clean, cold water. Allow the mixed adhesive to stand for a few minutes before re-mixing briefly. Using a notched trowel, spread the adhesive onto the wall in small sections, working in areas you can tile within 20-30 minutes.



## 04 FIX

Press the tiles firmly into the adhesive, using a slight twisting motion to ensure full contact and a solid bed fixing. Use tile spacers to maintain consistent gaps. Periodically check that the tiles are level and make adjustments as needed. Clean any excess adhesive from the tile surface and joints as you go. For edges and corners, cut tiles as necessary using a tile cutter or wet saw. Allow the adhesive to set according to the product instructions.



## 05 FINISH

Once the adhesive has set, remove tile spacers and prepare for grouting. Mix **Dunlop GX-500 Grout** according to the instructions and apply diagonally across the tile joints using a rubber float to ensure that the joints are completely filled. After about 15 minutes, clean the tile surface with a damp sponge and smooth the grout lines. Once dry, polish the tiles with a clean cloth and allow the grout to fully cure. Seal movement joints with **Dunlop FX-90 Silicone** where needed.



*Note: Always refer to the respective product datasheets before application.*